

MOTIVE POWER DIVISION



INSTALLATION AND OPERATING INSTRUCTIONS FerroCharge®

INDUSTRIAL BATTERY CHARGERS

PM990-1897-00, ISSUE 5

Issue History

ISSUE	PAGE(S)	DESCRIPTION	APP'D / DATE
1	All	Original Release	8/4/03
2	56	Correct 575v 3 -ph primary connection	4/16/04
3	53 to 60	Remove optional ammeter and reference to TB3 watering	2/15/05
4	5, 50-52	Add models, add French safety instructions	5/13/05
5	9,50-55, 59,62,65-82	Add Models, Cabinet B, and three transformer diagrams, add TVS to diagrams, MC4 photos SEE ECN 15704	MCM 9/20/06

Table of Contents

1.	IMPOR	RTANT SAFETY INSTRUCTIONS	7
2.	RECEI	VING AND INSTALLATION	
	2 1 D-		
	2.1. KE	CEIVING	
	2.2. IDE	ENTIFICATION	
	2.5. STO	ORAGE	
	2.4. LO 2.5 Mr	CATION	
	2.3. MIE 26 Eu	CHANICAL INSTALLATION	
	2.0. EL	AC Input voltage and voltage changeover	
	2.0.1.	AC input voltage cables	
	2.0.2.	Grounding	
	2.6.4	DC cables and cable connectors	12
	2.0.1. 2.7 MA	AINTENANCE	12
2	SCOUT		12
э.	SCOUL		
	3.1. DE	SCRIPTION	
	3.2. OP	ERATION	
	3.2.1.	Basic operation	
	3.3. BA	SIC SETTINGS	
	3.3.1.	Setting the number of cells	
	3.3.2. 3.3.3	Changing the five-second factory-set detay	
	3.3.3.	Cold Storage Setting	
	335	Manual equalizing	
	336	Automatic equalizing	
4	COMD		10
4.	COMP	UCHARGE 5 CONTROL	
	4.1. DE	SCRIPTION	
	4.2. Op	ERATION	
	4.3. BA	SIC SETTINGS	
	4.3.1.	Setting the precharge delay	
	4.3.2.	Activating cold storage	
	4.3.3.	Setting the number of cells	
	4.3.4.	Automatic equalizing	
	4.3.5.	Manual equalizing	
	4.3.0.	Automatic watering	
5.	COMP	UCHARGE 4	
	5.1. De	SCRIPTION	
	5.2. OP	ERATION	
	5.3. BA	SIC SETTINGS	
	5.3.1.	Setting the Precharge Delay	
	5.3.2.	Setting the Automatic Equalizing Frequency	
	5.3.3.	Setting the Equalize Charge Duration	
	5.3.4.	Setting the Refresh Charge Interval	
	5.3.5.	Setting the Number of Cells	
	5.3.6.	Setting the Shunt Size	
	5.3.7.	Setting the Operating Temperature	
	5.3.8.	Setting the Gassing Voltage	
	5.3.9.	Setting the Charge Profile	
	5.3.10.	Setting the Hold Time for Opportunity Charging	

	5.3.11.	Cooldown Timer at End of Charge	
	5.3.12.	Automatic watering	
6.	RANGE	R II CONTROL	
			20
6	1.1. Des	NCRIPTION	
C	621	Deal time or fixed increment starting	
	0.2.1. 6 2 2	Automatic equalizing	
	622	Automatic equalizing	
	0.2.3. 6 2 <i>1</i>	Satting and time	
	0.2.4.	Setting cool time	
	626	Monitoring water flow	
	0.2.0. 6 2 7	Main power overnide	
	628	Satting the number of calls	
	620	Selling the humber of cells	
	6210	Setting the rated output ourrant	
	0.2.10. 6 2 11	Setting the charge mode	
	6 2 12	Setting the data	
	0.2.12. 6 2 12	Setting the convect time	
	0.2.15.	Setting the day of the week	
	0.2.14.	A stingting double to grings time	
	0.2.15. 6 2 16	Activating adjught savings time	
	0.2.10.	Setting the band rate	
	0.2.17.	Setting the baua rate	
c	6.3. OPE	Manual et antique	
	0.3.1.	Manual Starring	
	0.3.2.	Manual suppling	
	0.3.3.	Manual equalizing	
	0.3.4.	Operation after loss of AC power (warm start)	
	0.3.3.	Charge data retrieval	
C	A. SPE	CIAL FEATURES WITH A COMPATIBLE BATTERY MODULE	
	0.4.1.	Installing a compatible battery module communications board	
	0.4.2.	Retrieving data from a compatible battery module	
C	0.5. COI	MMUNICATIONS PORT	
7.	CHARG	ER OPERATION	
7	'1 R EC	OMMENDED CHARGING PROCEDURES	36
7	.1. KEK 7 Opt	EXAMPLE CHARACTERISTICS	37
,	.2. 011		
8.	TROUB	LESHOOTING	
s	1 Gen	JEDAL TROUBLESHOOTING GUIDELINES	30
s c	2.1. OE		
5	1.2. IKC		
c S	2.4 DEI		
c	0.4. KEP	LACING COMPONENTS	
9.	MODEI	S, RATINGS, AND PARTS LISTS	
10	SCIII		52
10.	SCH	INIATICS AND WIRING DIAGRAMS	
	SCHE	MATIC DIAGRAM – 208/240/480 VAC 1- PHASE	53
	SCHE	MATIC DIAGRAM – 120/208/240 VAC 1- PHASE	54
	SCHE	MATIC DIAGRAM – 208/240/480 VAC 3-PHASE	
	SCHE	VIATIC DIACKANI – 208/240/480 VAC 5-PHASE THREE TRANSFORMERS	
	SCHE	νιατις διασκαίνι -400 γας β-γπαδε τηκέε τκαινδρυκινιεκδ	
	SCHE	MATIC DIAGRAM – 575 VAC 1- THASE.	
	SCHE	MATIC DIAGRAM – 575 VAC 3- PHASE THREE TRANSFORMERS	
	WIRIN	IG DIAGRAM - 1 PHASE - 208/240/480 VAC	61
	WIRIN	IG DIAGRAM - 1 PHASE - 120/208/240 VAC	62

WIRING DIAGRAM - 3 PHASE - 208/240/480 VAC	63
WIRING DIAGRAM - 3 PHASE - THREE TRANSFORMERS - 208/240/480 VAC	64
WIRING DIAGRAM - 3 PHASE - THREE TRANSFORMERS - 480 VAC	65
WIRING DIAGRAM - 1 PHASE - 575 VAC	66
WIRING DIAGRAM - 3 PHASE - 575 VAC	67
WIRING DIAGRAM - 3 PHASE - THREE TRANSFORMERS - 575 VAC	68

Figures and Tables Content

FIGURE 2.1 NAMEPLATE	
TABLE 2.1 AC INPUT VOLTAGE CODES	
FIGURE 2.2 CABINET DIMENSIONS	9
FIGURE 2.3 AC VOLTAGE RATING LABEL (VOLTAGE CIRCLED)	
FIGURE 2.4 AC FUSE RATING CHART. CIRCLES INDICATE THE PROPER FUSES FOR EACH VOLTAGE	
TABLE 2.2 ALLOWABLE AC INPUT RANGE	
FIGURE 3.1 SCOUT CONTROL BOARD	
FIGURE 3.2 SCOUT CONTROL BOARD JUMPERS	
FIGURE 3.3 JUMPERS FOR CHANGING CELLS	
FIGURE 3.4 JUMPERS FOR SETTING TURN ON DELAY	
FIGURE 3.5 JUMPERS FOR SETTING MAXIMUM CHARGING TIME	
FIGURE 3.6 JUMPERS FOR SETTING AUTOMATIC EQUALIZE	17
FIGURE 4.1 COMPUCHARGE 3 CONTROL	
FIGURE 4.2 JUMPERS FOR SETTING TURN ON DELAY	
FIGURE 4.3 JUMPERS FOR SETTING COLD STORAGE	
FIGURE 4.4 JUMPERS FOR SETTING THE NUMBER OF CELLS	
FIGURE 4.5 JUMPERS FOR SETTING AUTOMATIC EQUALIZE	
FIGURE 5.1 COMPUCHARGE 4 CONTROL (L) AND INTERFACE (R) BOARDS	
FIGURE 6.1 RANGER II CONTROL WITH COMMUNICATIONS BOARD	
FIGURE 7.1 TYPICAL FERRORESONANT CHARGER CURVES	
TABLE 8.1 TEST INSTRUMENTS AND TOOLS FOR TROUBLESHOOTING	
TABLE 8.2 DIODE CONNECTION TORQUE VALUES	

1. IMPORTANT SAFETY INSTRUCTIONS

INSTRUCTIONS IMPORTANTES CONCERNANT LA SÉCURITIÉ

- a. Read the instruction manual and all warning labels on the charger and battery before using the charger.
- b. Familiarize yourself with the locations of hazardous voltages within the cabinet.
- c. Danger: To prevent electric shock do not touch uninsulated live parts of the charger or battery. Danger: risque de chocs électriques. Ne pas toucher les parties non isolées du connecteur de sortie ou les bornes non isolées de l'accumulateur.
- d. Shut off the charger before connecting or disconnecting the battery. Press the STOP key before disconnecting the battery.
- e. The charger must be operated or serviced only by qualified personnel.
- f. De-energize the ac input and disconnect the battery before servicing the charger.
- g. Do not operate the charger outside its ratings as specified on the data nameplate.
- h. FerroCharge chargers are intended for charging lead acid batteries only. Attention : utiliser pour charger uniquement les accumulateurs du type au plomb. D'autres types d'accumulateurs pourraient éclater et causer des blessures ou dommages.
- i. Do not expose the charger to water or other liquids.
- j. FerroCharge chargers are intended for indoor use only.
 - CAUTION: DO NOT EXPOSE TO RAIN.

ATTENTION: NE PAS EXPOSER À LA PLUIE.

k. Chargers are equipped from the factory with a tag describing the ac input Voltage. If the tag does not match the available ac line the input must be reconnected and the fuse values changed following the instructions in this manual. CAUTION – DISCONNECT SUPPLY BEFORE CHANGING FUSES.

ATTENTION - COUPER L'ALIMENTATION AVANT DE REMPLACER LES FUSIBLES.

- 1. FerroCharge chargers are not intended for use in hazardous locations. Even if equipped with an explosion proof connector to match the battery, the charger must be located in a non-hazardous location.
- m. Check for wear on the dc cables and connector. Replace cables that have cracked insulation. Replace connectors that overheat, are melted, or with pitted contacts.

Legal Disclaimer

Any data, descriptions or specifications presented herein are subject to revision by C&D Technologies, Inc. without notice. While such information is believed to be accurate as indicated herein, C&D Technologies makes no warranty and hereby disclaims all warranties, express or implied, with regard to the accuracy or completeness of such information. Further, because the product(s) featured herein may be used under conditions beyond its control, C&D Technologies hereby disclaims all warranties, either express or implied, concerning the fitness or suitability of such product(s) for any particular use or in any specific application or arising from any course of dealing or usage trade. The user is solely responsible for determining the suitability of the product(s) featured herein for the user's intended purpose and in user's specific application.

Seller's liability for any breach of warranty is limited as set forth in seller's standard warranty applicable to the product ("the warranty"). The warranty is exclusive and offered in lieu of all other express, implied or statutory warranties including, without limitation, implied warranties of merchantability and fitness for a particular purpose. In no event shall the seller's liability for any damages arising out of any sale of products to buyer, and regardless of the legal theory on which such damages may be based, exceed the amount that supplier has received as payment for such products and under no circumstances shall supplier be subject to any consequential, incidental, indirect, special or contingent damages whatsoever, including but not limited to damages for lost profits or goodwill, even if supplier was advised of the possibility of such damages.

2. RECEIVING AND INSTALLATION

2.1. Receiving

Inspect the charger for any shipping and handling damage as soon as it arrives. Describe any damage on the receiving slip and immediately notify the shipper. Verify the model and serial numbers printed on the packing list against the nameplate (Figure 2.1). If they disagree, contact your representative before proceeding with installation. Use caution when moving chargers. Use the proper moving equipment. Do not drop or otherwise abuse the charger.

MODEL: IFR18HK1000 SPEC: XXXXXX SERIAL NUMBER: XXX00000 DC OUTPUT: 36 VOLTS 190 AMPS 18 CELLS LA RATED 8 HOUR CAPACITY: 1000 (100D6C8) AH AC INPUT: 208/240/480 VOLTS 3 PHASE 28/24/12 AMPS 60 HERTZ RECOMMENDED LINE FUSES: 40/40/20

FIGURE 2.1 NAMEPLATE

2.2. Identification

A six-element model number identifies each charger. Each element describes a different charger performance characteristic. The model number of a **FerroCharge** charger describes its basic operating characteristics. A typical model number is:

IFR	-	Product Family
12	-	Number of (Lead-Acid) Cells in Battery to be charged
HK	-	AC Input Voltage Code, See Table 2.1
1000	-	Ampere-Hour Rating for 8-Hour Charge

AC INPUT VOLTAGE CODES		
Code	Input (VAC) and Phase Frequency	
		(Hz)
AC	120/208/240, 1-Phase	60 Hz
CE	208/240/480, 1-Phase	60 Hz
HK	208/240/480, 3-Phase	60 Hz
М	575, 1-Phase	60 Hz
К	480, 3-phase	60 Hz
L	575, 3-Phase	60 Hz

TABLE 2.1 AC INPUT VOLTAGE CODES

2.3. Storage

Keep the charger in its original shipping container until it is ready to be installed. The unit can be safely stored in any clean, dry area where temperatures remain between 40° F and 120° F (5°C and 50°C).

2.4. Location

Battery charging produces heat and a potentially explosive mixture of odorless oxygen and hydrogen gases. Safe charging requires a clean, dry, well-ventilated area. For long battery life the room temperature should be between $60^{\circ}F$ and $90^{\circ}F$ ($16^{\circ}C$ and $32^{\circ}C$). Refer to the battery manufacturer's recommendations. The charger is rated to operate in ambient temperatures between $60^{\circ}F$ and $104^{\circ}F$ ($16^{\circ}C$ and $40^{\circ}C$). The charger may be operated for limited periods (up to 4 hours) at ambient temperatures between $104^{\circ}F$ and $122^{\circ}F$ ($40^{\circ}C$ to $50^{\circ}C$).

FerroCharge chargers are natural convection-cooled. Chargers require a MINIMUM of four inches of clearance between the floor, walls, chargers, and other obstructions for adequate air circulation. EXPLOSIVE, COMBUSTIBLE or FLAMMABLE MATERIALS SHOULD NOT BE PERMITTED IN THE CHARGING ROOM. NEVER MOUNT A CHARGER ON OR ABOVE COMBUSTIBLE MATERIALS. NE PAS INSTALLER SUR DES SURFACES COMBUSTIBLES OU AU-DESSUS DE TELLES SURFACES.

To prevent the accumulation of explosive concentrations of hydrogen and oxygen, the charging area should have sufficient ventilation to prevent formation of one percent, by volume, of hydrogen. It is important to note hydrogen is generated at different rates during various times in the charger cycle. Most of the gas forms during the last two to three hours of the charge when the average cell potential exceeds 2.37 volts. Every pint of water dissociated during recharge releases 23 cubic feet of hydrogen gas to the atmosphere. To calculate hydrogen formation, multiply the number of pints of water needed to correctly re-level cells after charging then multiply the number by 23. Thus, a lead-acid motive power battery that requires 1.5 pints of water to re-level, will produce 34.5 cubic (1.5 X 23) feet of hydrogen.

An approximation technique may be used to estimate hydrogen production from batteries charged by chargers equipped with CompuCharge and Ranger controls. It is estimated a total of 0.24 cubic feet of hydrogen gas will evolve from each cell per 100 ampere-hours of capacity. For example, an 18-cell battery rated at 720 ampere-hours:

Cells x Capacity x 0.24/100 = Cubic feet of hydrogen/charge cycle

 $18 \times 720 \times 0.24/100 = 31.1$ Cubic feet of hydrogen/charge cycle

2.5. Mechanical installation

Chargers can be bolted to noncombustible floors or steel benches. Consult Figure 2.2 for charger cabinet dimensions. Wall mounting requires optional brackets, part number KBC05889A, quantity 2.

Cabinet	Height	Width	Depth
А	26.062 In	21.75 In	22.75 In
А	662 mm	552 mm	578 mm
В	26.062 In	32 In	22.75 In
В	662 mm	813 mm	578 mm



FIGURE 2.2 CABINET DIMENSIONS

2.6. Electrical connection

Each charger requires a fused safety disconnect switch or a circuit breaker. Use a line protection device rated for the recommended line fuse value shown on the charger nameplate (Figure 2.1). Electrical installations must be performed by a qualified electrician and satisfy all local, national and federal electrical codes. Proper grounding is required both for safety and to ensure optimum noise and transient immunity of the control board. Refer to the following sections for more specific information.

CAUTION

Electrical connections can work loose during shipping. Check all connections for tightness before connecting the charger to the AC supply voltage.

2.6.1. AC Input voltage and voltage changeover

The voltage circled on the input voltage rating label (Figure 2.3) must match the available line voltage. If the voltages are different, it will be necessary to change the AC line fuses, the control transformer fuse, and the connection terminals on both the ferroresonant power transformer and the control transformer. Consult the voltage changeover instruction label inside the cabinet door and the schematics or wiring diagrams at the back of this manual. BE SURE THE CHARGER IS DISCONNECTED FROM ITS AC POWER SUPPLY AND THE BATTERY BEFORE ATTEMPTING THIS MODIFICATION.

CAUTION – DISCONNECT SUPPLY BEFORE CHANGING FUSES. **ATTENTION** - COUPER L'ALIMENTATION AVANT DE REMPLACER LES FUSIBLES.

NOTE: AC voltage changeover must be made at the terminals of both the ferroresonant power transformer and the control transformer.

Input voltage changeover CANNOT BE PERFORMED on chargers manufactured for 575 VAC only operation.

CAUTION

DO NOT ATTEMPT TO RECONNECT VOLTAGE WITHOUT READING INSTRUCTIONS



FIGURE 2.3 AC VOLTAGE RATING LABEL (VOLTAGE CIRCLED)

CAUTION AC FUSE RATING			
USE TYI	PES NOS, N	ILS, OR OTS	S ONLY
208V	240V	480V	575V
345	345	345	345
678	678	678	678
10 12 15	10 12 15	10 12 15	10 12
20 25 30	20 25 30	20 25 30	15 20
35 40 45	35 40 45	35 40 45	25 30
50 60	50 60	50 60	35 40

FIGURE 2.4 AC FUSE RATING CHART. CIRCLES INDICATE THE PROPER FUSES FOR EACH VOLTAGE.

2.6.2. AC input voltage cables

Customers or electrical contractors must furnish the AC connection. Cables should be sized for the recommended line fuse values shown on the charger nameplate. Allowable variations from nominal AC line voltages appear in Table 2.2. Route the AC conduit through the knockout provided in the charger cabinet. Connect the cables to the fuseblock terminals.

CAUTION – USE MINIMUM 75°C WIRING. USE COPPER CONDUCTORS. **ATTENTION** - EMPLOYER DES FILS POUR AU MOINS 75 DEG C

Nominal AC Voltage	AC Voltage Range
120	106-127
208	184-220
240	212-254
480	424-508
575	508-600*

TABLE 2.2 ALLOWABLE AC INPUT RANGE Input range

*The charger will operate up to 632 VAC, but certain kinds of control and protective equipment have a maximum voltage limit of 600V. The manufacturer or power supplier or both should be consulted to assure proper application.

2.6.3. Grounding

The charger chassis must be grounded to the AC power source per the requirements of the National Electrical Code and applicable local codes. In order to assure dependable operation, it is imperative that the charger be provided a reliable earth ground. A solderless connector (lug) is provided on the floor of the cabinet near the AC fuseblock.

WARNING - THERE IS RISK OF ELECTRICAL SHOCK IF THE CHARGER IS NOT PROPERLY GROUNDED

2.6.4. DC cables and cable connectors

Each charger ships with a standard, eight-foot long cable that terminates with an appropriate connector. As an option, other lengths are available. If it is necessary to install longer cables, they must be properly sized to prevent overheating and ensure compliance with electrical codes.

When specifying replacement DC output connectors, it is important to remember single-phase chargers produce higher peak currents than similarly rated three-phase systems. The maximum DC current flowing from a single-phase charger is typically 1.3 times the ammeter reading. Higher capacity SB-350 connectors are recommended as retrofit equipment for all single-phase chargers rated at over 135 amperes.

DC CABLE LENGTHS FROM 15 TO 25 FEET SHOULD BE ONE CABLE SIZE LARGER THAN THE STANDARD CABLE. CABLE LENGTHS FROM 25 TO 35 FEET SHOULD BE TWO CABLE SIZES LARGER. DC CABLE LENGTHS SHOULD NOT EXCEED 35 FEET.

CAUTION

Be sure the charger positive terminal is connected to the charger connector terminal marked (+) and the negative terminal to the one marked (-).

2.7. Maintenance

Battery chargers work most efficiently and deliver better service life with good heat dissipation. Periodic cleaning with dry, low-pressure air will remove accumulated dust to assure good heat transfer to the surrounding air. At least twice a year, check input and output circuit connections and ground connections to make sure they are tight.

The DC cables and DC connector require periodic maintenance. Inspect the DC cables and DC connector to verify a sound, low-resistance connection, that there is no exposed metal, and that the connector is mechanically intact. Dirty or pitted contacts should be cleaned and lubricated or replaced following the manufacturer's recommendations. Cables should be replaced if the insulation is cut or cracked, or if the copper is exposed.

There are no other maintenance adjustments to the **FerroCharge** chargers.

CAUTION: Disconnect charger from AC voltage supply before servicing or dismantling.

3. SCOUT CONTROL

3.1. Description

The SCOUT CONTROL is a microprocessor-based controller that minimizes overcharging by continually monitoring battery voltage. Other STANDARD features include:

- Automatic start-helps prevent operator errors
- dV/dt termination
- Adjustable start delay
- Automatic equalization
- Safety features-checks for correct battery before charge begins
- Maximum charge time-helps prevent overheating
- Abort feature-when the control senses a problem, the red LED flashes twice every second



FIGURE 3.1 SCOUT CONTROL BOARD

3.2. Operation

3.2.1. Basic operation

SERIES chargers equipped with the SCOUT control have an LED display and keypad for operator interface. One LED indicates the charger is ready to operate, another LED indicates the battery is being charged and a third LED indicates when gassing voltage is reached. The Equal key activates the equalization charge mode and the Stop key allows the charger to be turned off during a charge.

Chargers equipped with the SCOUT control do not have start switches. Charging automatically begins five seconds after the operator connects the battery, unless the user specifies another delay (refer to Section 3.3.2).

When no battery is connected, the green LED will flash briefly every four seconds to indicate the charger is ready to begin charge. Once a battery is connected, the red LED will flash and glow steadily when the charge is in progress. When the battery is 80 percent charged, the yellow LED is lit, and the red LED will be extinguished. When the charge is complete, the green LED will glow.

If equalize is selected, the charge is extended by three hours. The red LED will flash when the battery is connected and during the charge. During equalization, the yellow LED will flash and will continue to do so throughout the equalize cycle. When the charge is complete, the green LED will flash.

If a battery with a number of cells that do not match the charger rating is connected, the charger will not start. Refer to Section 8, Troubleshooting.

If AC power is interrupted, charging will restart after a randomly timed start-up delay, not exceeding three minutes, thirty seconds. The random delay prevents a large inrush from the ac line if all chargers were to start at the same time.

In the event of an accidental battery disconnect, the system will shut down automatically, protecting charger components.

WARNING

If it is necessary to disconnect the battery during the charge, press the stop key before disconnecting the battery. FAILURE TO TAKE THIS PRECAUTION CAN CAUSE A SERIOUS ARC HAZARD AND A POTENTIALLY SERIOUS INJURY.

3.3. Basic settings

3.3.1. Setting the number of cells

The SCOUT control has jumpers to set the number of cells, 6, 12, 18, 24 or 36, to match the charger rating. The SCOUT is shipped from the factory matched to the charger. ADJUSTMENT OF THIS FEATURE IS NEEDED ONLY WHEN THE PRINTED CIRCUIT BOARD HAS BEEN REPLACED.

To change the number of cells:

- 1) Disconnect the ac power supply at the circuit breaker or fused safety-disconnect.
- 2) Open the instrument panel and locate the printed circuit board mounted directly behind it.
- 3) Locate the configuration jumpers as shown in Figure 3.2.
- 4) Move the jumpers to the desired number of cells, as shown in Figure 3.3.
- 5) Close the cabinet and reconnect the AC power supply.

JP8
(🛛 🔿 EQU 10c
7 (🛛 🔿 EQU 7c
6 (O)EQU never
5 回 🔿 36 cells
4 回 🛛 24 cells
3 (🛛 🔿 18 cells
2 (00)12 cells
1 🔍 0 6 cells
9 (00) 55 delay
10 ()30s delay
11 🔍 O 1hr delay
12004hr delay
130012hr max
14(00)24hr max

FIGURE 3.2 SCOUT CONTROL BOARD JUMPERS

JP8 (O)EQU 10c 7 (0)EQU 7c 6 (D) EQU never 5/00)36 cells (□ <u>0</u>)24 ce\ls 432 00)18 cells 0012 ce/ls 006 cells 1 9 0055 delay 10 0 30s delay 11 💿 1hrdelay 1200 4hrdelay 130012hrmax 1400)24hrmax

FIGURE 3.3 JUMPERS FOR CHANGING CELLS

3.3.2. Changing the five-second factory-set delay

The SCOUT control is shipped with a preset, five-second safety-delay. The delay can be changed to 30 seconds, one hour, or four hours.

To lengthen the factory-set delay:

- 1) Disconnect the battery and disconnect the ac power supply at the circuit breaker or fused disconnect.
- 2) Open the cabinet door. Remove the screws at the bottom of the instrument panel. Swing out the instrument panel.
- 3) Locate the bank of configuration jumpers on the control board as shown in Figure 3.2.
- 4) Move the jumpers to the desired time pattern: 30 seconds, one hour, or four hours. Refer to Figure 3.4.
- 5) Close all the panels and doors.
- 6) Reconnect the ac power supply.



FIGURE 3.4 JUMPERS FOR SETTING TURN ON DELAY

3.3.3. Changing maximum charging time

The maximum charging time is factory-set at 12 hours. This feature should not need adjustment.



FIGURE 3.5 JUMPERS FOR SETTING MAXIMUM CHARGING TIME

3.3.4. Cold Storage Setting

The SCOUT control may be set to extend the charge by 30 minutes for cold storage or similar applications. A special combination of the override timer settings is used for this feature.

Place jumpers on both positions 13 and 14, 12hr max and 24hr max, to add 30 minutes of charging time with a 12-hour maximum charge time. Refer to Figure 3.5.

3.3.5. Manual equalizing

To initiate an equalization charge the operator connects the battery, waits for the red LED to flash or glow, and then presses the Equal key on the keypad. At the conclusion of an equalize charge the system automatically returns to the daily charge mode. The operator may initiate or terminate an equalize charge by pressing the Equal key while the charger is charging. If the charger is in the equalize part of the charge it will stop when the Equal key is pressed.

3.3.6. Automatic equalizing

The SCOUT control can be set to automatically equalize never, every seventh cycle, or every tenth cycle. To set the automatic equalization:

- 1) Disconnect the AC power supply at the circuit breaker or fused disconnect panel.
- 2) Open the cabinet door. Remove the screws at the bottom of the instrument panel. Swing out the instrument panel.
- 3) Locate the bank of configuration jumpers on the control board as shown in Figure 3.2.
- 4) Move the jumpers to the desired equalize cycle. The factory setting is 7 cycles. Refer to Figure 3.6.
- 5) Close all the panels and doors.
- 6) Reconnect the ac power supply.

IF 10 O)EQU Noc (D O)EQU 72 (DEQU never 6 5 (0 0)36 cells (00)24 cells 4 3 (0 0)18 cells 2 (<u>0</u>)12 cells 1 (<u>0</u>)6 cells 9 (00)55 delay 10 (0 0) 30s delay 11 🔍 1hrdelay 12(0) 4hrdelay 13(00)12hrmax 14 (0 0) 24 hrmax

FIGURE 3.6 JUMPERS FOR SETTING AUTOMATIC EQUALIZE

4. COMPUCHARGE 3 CONTROL

4.1. Description

The COMPUCHARGE 3 CONTROL is a microprocessor-based controller that reduces the chance for overcharging by continually monitoring battery voltage and current. Other COMPUCHARGE 3 control features include:

- Automatic start-helps prevent operator errors
- dV/dt and dI/dt termination
- Turn-on time delay Five seconds to seven hours, 45 minutes in 15 minute increments
- Automatic equalize Never, every seven days, 1, 2, 3, 4, 5, 6, or 7 cycles
- Safety features-checks for correct battery before charge begins
- Maximum charge time-helps prevent overheating
- 4-digit, seven segment easy to read LED display
- Fully charged battery detector won't start if detected
- Hot battery detector will terminate charge and resume after 8 hours cooling
- Automatic watering control output



FIGURE 4.1 COMPUCHARGE 3 CONTROL

4.2. Operation

The operating panel of the COMPUCHARGE 3 control is a sealed membrane with a four character, ¹/₂ inch LED display, a Stop key, an Equal key, and a Scroll key.

The charging cycle is initiated when the battery is connected. The COMPUCHARGE 3 control checks for a battery of the proper voltage. If the match is correct, the display will show a count down until the charge starts. If a mismatch is detected, an error code ("bU E") will appear. (Refer to the troubleshooting section for more information.)

If an equalize charge is selected either automatically or by pressing the Equal key, a dot will appear on the display after the last character on the right. If automatic equalize is selected it will flash. If manual equalize is selected it will not flash. A manual equalize may be canceled by pressing the Equal key again.

After the user-selected start up delay the charge cycle begins. (For safety reasons the minimum delay is factory set at five seconds.) The charge current is displayed during the charge.

The COMPUCHARGE 3 control monitors the change in voltage and current to determine when the charge should be terminated. When the charge is greater than 80% completed, the last digit on the display will flash.

Pressing the Scroll key at any time during the charge cycle will display the battery voltage ("99.9U"). Pressing the Scroll key twice displays the Ampere-hours returned ("999r"). The display will return to the charging current after 60 seconds, or if the Scroll key is pressed a third time.

Charging continues until the battery is fully charged and the cell electrolyte is mixed. If the battery remains connected to the charger for three days, a refresh charge will be initiated automatically.

Cells nearing the end of their operating life or mistreated batteries may be unable to accept a complete charge. If the charge termination criteria have not been met after 12 hours, the charge cycle is stopped and an error message is displayed ("12hE").

When ac power is interrupted during a charge, charging will restart after a randomly timed startup delay not exceeding two minutes. The random delay prevents a large inrush from the ac line if a group of chargers were to start at the same time.

If a fully charged battery is inadvertently connected to the charger it will be detected and the charge terminated within three minutes.

A hot battery that goes into thermal runaway will be detected. The charger will stop for 8 hours, and then resume in the state where it left off. Typically thermal runaway only occurs as the battery approaches full charge.

4.3. Basic Settings

4.3.1. Setting the precharge delay

The precharge delay may be set to take advantage of lower utility rates. To change the precharge delay, follow these steps:

- 1) Disconnect the battery and disconnect the ac power supply at the circuit breaker or fused disconnect.
- 2) Open the cabinet door. Remove the screws at the bottom of the instrument panel. Swing out the instrument panel.
- 3) Locate the bank of configuration jumpers on the control board as shown in Figure 4.2.
- 4) Move the jumpers to the desired setting. When multiple jumpers are used the delay times are additive. For example, placing jumpers on 15 minutes, 2 hours, and 4 hours will set the delay to 6 hours and 15 minutes. Refer to Figure 4.2. Extra jumpers are located on the upper right hand corner of the board.
- 5) Close all the panels and doors.
- 6) Reconnect the ac power supply.



FIGURE 4.2 JUMPERS FOR SETTING TURN ON DELAY

4.3.2. Activating cold storage

Users with a cold storage application can set the COMPUCHARGE 3 control to adjust its charge termination. Battery starting temperatures of below 55°F are considered cold storage. To select this option, place jumpers on both the "temp norm" and "temp cold" pins (use two jumpers). Refer to figure 4.3.



FIGURE 4.3 JUMPERS FOR SETTING COLD STORAGE

4.3.3. Setting the number of cells

The COMPUCHARGE 3 control is set up to match the charger. It has adjustments for a variable number of cells -6, 9, 12, 15, 16, 18, 20, 24, 32, 36, and 40.

To change the number of cells:

- 1) Disconnect the battery and disconnect the ac power supply at the circuit breaker or fused disconnect.
- 2) Open the cabinet door. Remove the screws at the bottom of the instrument panel. Swing out the instrument panel.
- 3) Locate the bank of configuration jumpers on the control board as shown in Figure 4.4.
- 4) Move the jumpers to the desired number of cells. Refer to Figure 4.4. For 9, 15, 16, 20, 32, and 40 cells multiple jumpers are required as shown in the following table:

Cells	Jumpers on
9	6 and 12 cell
15	12 and 18 cell
16	6, 12, and 18 cell
20	18 and 24 cell
32	24 and 36 cell
40	6 and 24 cell

- 5) Close all the panels and doors.
- 6) Reconnect the ac power supply.



FIGURE 4.4 JUMPERS FOR SETTING THE NUMBER OF CELLS

4.3.4. Automatic equalizing

The COMPUCHARGE 3 control can be set to automatically equalize never, every 7 days, or every 1, 2, 3, 4, 5, 6, or 7 cycles.

To change the automatic equalize setting:

- 1) Disconnect the battery and disconnect the ac power supply at the circuit breaker or fused disconnect.
- 2) Open the cabinet door. Remove the screws at the bottom of the instrument panel. Swing out the instrument panel.
- 3) Locate the bank of configuration jumpers on the control board as shown in Figure 4.1 that start with "EQU".
- 4) Move the jumpers to the desired equalize setting. The factory setting is 7 days. Refer to Figure 4.5.
- 5) Close all the panels and doors.
- 6) Reconnect the ac power supply.

Note: The equalize cycles are designed for maximum flexibility, so multiple jumpers placed in the banks ending in "cyc" are additive. For example, a jumper on the pin marked "EQU 1 cyc" and a jumper on the pin marked "EQU 2 cyc" would result in an equalize charge every three cycles. A single jumper on the pin marked "EQU 1 cyc" results in equalize every cycle. "NEVER" takes precedence over all other jumpers. Spare jumpers are located on the control board.



FIGURE 4.5 JUMPERS FOR SETTING AUTOMATIC EQUALIZE

4.3.5. Manual equalizing

To begin manual equalize, connect the battery and press the Equal key. Press the Equal key again to take the charger out of equalize.

4.3.6. Automatic watering

The COMPUCHARGE 3 control has a 24 VAC output to power a solenoid for automatic watering. One side of the solenoid connects to pin 5 of the control board and the other side of the solenoid connects to X4 on the control transformer (CXF). Refer to the schematics at the back of this manual.

The watering cycle lasts for 3 minutes at the end of charge. If equalize is set, the watering cycle precedes the equalize cycle. If the charger is equipped with a watering module, watering is automatic; there are no settings required.

Refer to the instructions supplied with the water module for installation and connections to the charger, and for connections to the water supply. Refer to the instructions supplied with the battery filling system for installation on the battery.

5. COMPUCHARGE 4

5.1. Description

The CompuCharge 4 is a microprocessor-based controller that reduces the chance for overcharging by continually monitoring battery voltage and current. The settings are menu driven and accessible from the front panel membrane switches. Other CompuCharge 4 features include:

- Automatic start-helps prevent operator errors
- dV/dt and dI/dt termination
- Turn-on time delay 5, 10, 30, 60 seconds; 0.1, 0.2, 0.5, 1, 2, 5, 8, and 12 hours
- Manual or automatic equalize None, 1 to 7 cycles, 7 days, or 14 days. Default is 7 cycles. Equalize duration of 1 to 6 hours, default is 3 hours. Equalize is indicated when the decimal point after the rightmost digit flashes.
- Checks for correct battery voltage before charge begins
- Maximum charge time of 12 hours helps prevent overheating.
- 4-digit, seven segment easy to read LED display for menu setup, current, Voltage, and accumulated Ampere-hours
- Gassing voltage set points of 2.37 or 2.40 Volts per cell
- Operating environment setting for normal or cold temperature
- Refresh charge mode settable for intervals of 3, 6, 8, 12, 15, 20, 24, 30, 40, 48, 60, or 72 hours. The default is 72 hours.
- 100 hour cooldown timer after end of charge helps to select the next battery to use
- Opportunity charging mode that Stops charge at gassing voltage. Settable hold time until full charge commences of 3, 6, 8, or 12 hours
- Fully charged battery detector won't continue to charge if detected
- Hot battery detector will terminate charge and resume after 8 hours cooling
- Automatic watering control output
- All display segments light before start of charge to indicate proper operation



FIGURE 5.1 COMPUCHARGE 4 CONTROL (L) AND INTERFACE (R) BOARDS

5.2. Operation

The operating panel of the **CompuCharge 4** control is a sealed membrane with a four character, ½ inch 7-segment LED display. There are three membrane switches, Stop, Equalize, and Scroll (curved arrow) used to enter the setup menu and select the setup parameters or to display Volts or Ampere-hours accumulated during the charge cycle.

The 7-segment display shows the number of cells during the idle mode. The charging cycle is initiated when the battery is connected. The **CompuCharge 4** control checks for a battery of the proper voltage. If the match is correct, the display will show a count down until the charge starts. If a mismatch is detected, the display will show "**bV E**". (Refer to the troubleshooting section for more information.)

After the user-selected start up delay the charge cycle begins. (For safety reasons the minimum delay is factory set at five seconds.) The charge current is displayed during the charge.

The **CompuCharge 4** control monitors the change in voltage and current to determine when the charge should be terminated. When the charge is greater than 80% completed, the last digit on the display will flash.

Pressing the scroll key at any time during the charge cycle will display the battery Volts per cell ("**XX.XV**"). Pressing the key twice displays the Ampere-hours returned ("**999r**"). The display will return to the charging current after 60 seconds, or if the key is pressed a third time.

Charging continues until the battery is fully charged and the cell electrolyte is mixed. If the battery remains connected to the charger, a refresh charge will be initiated automatically after a selected interval.

The CompuCharge 4 has an automatic equalize feature that extends the charge to mix the battery electrolyte and equalize the cell voltages. The decimal point to the right of the rightmost digit flashes to indicate the charger is in the equalize mode.

Cells nearing the end of their operating life or mistreated batteries may be unable to accept a complete charge. If the battery is not charged in 12 hours the charger will Stop and the display will show "**12hE**".

When ac power is interrupted during a charge, charging will restart after a randomly timed startup delay not exceeding two minutes. The random delay prevents a large inrush from the ac line if a group of chargers were to start at the same time. A battery that is mostly charged may show as fully charged after restarting.

If a fully charged battery is inadvertently connected to the charger it will be detected and the charge terminated within three minutes.

A hot battery that goes into thermal runaway will be detected. The charger will Stop for 8 hours, then resume in the state where it left off. Typically thermal runaway only occurs as the battery approaches full charge.

If the Stop key is pressed the display will show "StPE". The battery must be disconnected to clear the display.

5.3. Basic Settings

5.3.1. Setting the Precharge Delay

The precharge delay may be set to take advantage of lower utility rates. To change the precharge delay, follow these steps:

- 1) Press the Stop key and disconnect the battery to return to the idle mode.
- 2) Press and hold both the Equalize and Scroll keys for 5 seconds until the display goes to the setup menu. The first menu item is the delay.
- 3) Press the Equalize key until the desired setting of 5S (seconds), 10S, 30S, 60S; 0.1, 0.2H (hours), 0.5H, 1H, 2H, 5H, 8H, or 12H is reached
- 4) Press the Stop key to exit the menu or press the Scroll key to go to the next setting.

5.3.2. Setting the Automatic Equalizing Frequency

The **CompuCharge 4** can be set to automatically equalize none, every 1, 2, 3, 4, 5, 6, or 7 cycles, or every 7 or 14 days. The decimal point to the right of the rightmost digit flashes to indicate the charger is in the equalize mode.

To change the automatic equalize setting:

- 1) Press the Stop key and disconnect the battery to go to the idle mode.
- 2) Press and hold both the Equalize and Scroll keys for 5 seconds until the display goes to the setup menu. The second menu item is the delay.
- 3) Press the Scroll key until the display shows "E no", "E XC", or "EXXd".
- 4) Press the Equalize key until the desired setting of None, 1 to 7 cycles, 7 days, or 14 days is reached. Default is 7 cycles.
- 5) Press the Stop key to exit the menu or press the Scroll key to go to the next setting.

5.3.3. Setting the Equalize Charge Duration

To change the automatic equalize setting:

- 1) Press the Stop key and disconnect the battery to return to the idle mode.
- 2) Press and hold both the Equalize and Scroll keys for 5 seconds until the display goes to the setup menu. The third menu item is the equalize duration.
- 3) Press the Scroll key until the display shows "EdXh".
- 4) Press the Equalize key until the desired setting of 1, 2, 3, 4, 5, or 6 hours is reached. Default is 3 hours.
- 5) Press the Stop key to exit the menu or press the Scroll key to go to the next setting.

5.3.4. Setting the Refresh Charge Interval

The **CompuCharge 4** can be set to perform a refresh charge if the battery remains connected for 3, 6, 8, 12, 15, 20, 24, 30, 40, 48, 60, 72, or 80 hours.

To change the refresh charge interval:

- 1) Press the Stop key and disconnect the battery to return to the idle mode.
- 2) Press and hold both the Equalize and Scroll keys for 5 seconds until the display goes to the setup menu. The fourth menu item is the refresh interval.
- 3) Press the Scroll key until the display shows "**r**XX**h**".
- 4) Press the Equalize key until the desired setting of 3, 6, 8, 12, 15, 20, 24, 30, 40, 48, 60, 72 or 80 hours. The default is 12 hours.
- 5) Press the Stop key to exit the menu or press the Scroll key to go to the next setting.

5.3.5. Setting the Number of Cells

The CompuCharge 4 must be set to match the rating of the charger in which it is installed.

To set the number of cells:

- 1) Press the Stop key and disconnect the battery to return to the idle mode.
- 2) Press and hold both the Equalize and Scroll keys for 5 seconds until the display goes to the setup menu. The fifth menu item is the number of cells.
- 3) Press the Scroll key until the display shows "C XX".
- 4) Press the Equalize key until the desired setting of 6, 9, 12, 15, 16, 18, 20, 24, 32, 36, or 40 is reached.
- 5) Press the Stop key to exit the menu or press the Scroll key to go to the next setting.

5.3.6. Setting the Shunt Size

The CompuCharge 4 must be set to match the rating of the charger in which it is installed.

To set the shunt size:

- 1) Press the Stop key and disconnect the battery to return to the idle mode.
- 2) Press and hold both the Equalize and Scroll keys for 5 seconds until the display goes to the setup menu. The sixth menu item is the shunt size.
- 3) Press the Scroll key until the display shows "S XXX".
- 4) Press the Equalize key until the desired setting of 100A, 200A, 300A, 500A, or 600A is reached.
- 5) Press the Stop key to exit the menu or press the Scroll key to go to the next setting.

5.3.7. Setting the Operating Temperature

The default setting is normal or "**Tnor**". Users with a cold storage application can set the **CompuCharge 4** control to adjust its charge termination. Battery starting temperatures of below 55°F are considered cold storage.

To set the operating temperature and extend the charge time:

- 1) Press the Stop key and disconnect the battery to return to the idle mode.
- 2) Press and hold both the Equalize and Scroll keys for 5 seconds until the display goes to the setup menu. The seventh menu item is the operating temperature.
- 3) Press the Scroll key until the display shows "**Tnor**" or "**Tcol**".
- 4) Press the Equalize key to select normal, Tnor, or cold, Tcol.
- 5) Press the Stop key to exit the menu or press the Scroll key to go to the next setting.

5.3.8. Setting the Gassing Voltage

The CompuCharge 4 control may be set to detect a gassing point Voltage of 2.37 or 2.40 Volts per cell.

To set the gassing voltage detector:

- 1) Press the Stop key and disconnect the battery to return to the idle mode.
- 2) Press and hold both the Equalize and Scroll keys for 5 seconds until the display goes to the setup menu. The eighth menu item is the gassing voltage limit.
- 3) Press the Scroll key until the display shows "G2.37" or "G2.40".
- 4) Press the Equalize key to select 2.37 or 2.40.
- 5) Press the Stop key to exit the menu or press the Scroll key to go to the next setting.

5.3.9. Setting the Charge Profile

The **CompuCharge 4** control may be set for either a conventional or opportunity charging profile. In the opportunity charging mode the charger will Stop when the voltage reaches the gassing point. If the battery remains connected beyond a selected interval, a complete charge cycle will be performed.

To set the charge profile:

- 1) Press the Stop key and disconnect the battery to return to the idle mode.
- 2) Press and hold both the Equalize and Scroll keys for 5 seconds until the display goes to the setup menu. The ninth menu item is the charge profile mode
- 3) Press the Scroll key until the display shows "PrCV" or "PrOP".
- 4) Press the Equalize key to select conventional mode, "PrCV" or opportunity mode, "PrOP".
- 5) Press the Stop key to exit the menu or press the Scroll key to return to the beginning of the menu settings.

5.3.10. Setting the Hold Time for Opportunity Charging

In the opportunity charging mode the **CompuCharge 4** control may be set to wait for 3, 6, 8, or 12 hours after the charger Stops after reaching the gassing point to begin a full conventional charge cycle.

To set the hold time:

- 1) Press the Stop key and disconnect the battery to return to the idle mode.
- 2) Press and hold both the Equalize and Scroll keys for 5 seconds until the display goes to the setup menu. The ninth menu item is the charge profile mode
- 3) Press the Scroll key until the display shows "PrCV" or "PrOP".
- 4) Press the Equalize key to select the opportunity charging mode, "PrOP".
- 5) Press the Scroll key to display "**H**XX**h**", the hold time.
- 6) Press the Equalize key to select 3, 6, 8, or 12 hours.
- 7) Press the Stop key to exit the menu or press the Scroll key to go to the next setting.

5.3.11. Cooldown Timer at End of Charge

The **CompuCharge 4** control displays the hours and minutes, "**H.MMC**" or hours and tenths of hours, "**HH.HC**" since the charge ended up to 100 hours. This feature may be used to select the next battery to place back into use. The rate of change of the last two digits on the clock determines if they are seconds or minutes. After 100 hours the display will show "**COOL**".

5.3.12. Automatic watering

The **CompuCharge 4** control has a 24 VAC output to power a solenoid for automatic watering. One side of the solenoid connects to pin 5 of the control board and the other side of the solenoid connects to X4 on the control transformer (CXF). Refer to the schematics at the back of this manual.

The watering cycle lasts for 3 minutes at the end of charge. If equalize is set, the watering cycle precedes the equalize cycle. If the charger is equipped with a watering module, watering is automatic; there are no settings required.

Refer to the instructions supplied with the water module for installation and connections to the charger, and for connections to the water supply. Refer to the instructions supplied with the battery filling system for installation on the battery.

6. RANGER II CONTROL

6.1. Description

The RANGER II control uses a "plain-English," menu-driven display program. When the charger is idle, the display shows the number of cells, the current date and the time.

Features of the RANGER II control include:

- Bright, two-line vacuum fluorescent display-visible in ambient light
- "Plain English," menu-driven display-for fast set-up, preview and change of equalize, delayed start and other charge parameters
- **Delayed start**-turn-on time delay is selectable from five seconds to 12 hours in one second intervals and time of day start
- Real-time 24-hour clock-with automatic adjustment for daylight savings time.
- Automatic or manual equalize–automatic equalize selectable from one to 50 cycles or day of the week; manual equalize selectable from front panel
- Automatic three-day refresh cycle- if battery is connected for more than 72 hours, a brief boost charge is provided to maintain battery in fully charged condition
- Automatic charge termination- when voltages stabilize indicating full charge or if battery overheats
- User programmable cool down step
- A variety of cell and shunt sizes-selectable for six through 36-cell batteries and four shunt sizes
- Output for optional automatic watering device
- Advanced features with compatible battery module:
- Equalize by battery cycles
- Watering by cycles
- **Manual equalize and charger reports** can be accessed by pressing the Scroll key (curved arrow). Refer to sections 6.3.3 for specific information.



FIGURE 6.1 RANGER II CONTROL WITH COMMUNICATIONS BOARD

6.2. Basic Settings

Basic control settings such as number of cells, shunt size, delay before starting, etc. are set from the front panel using a "hidden" menu with restricted access. Before operating your charger, check to be sure these initial settings have not been changed. Should you need to change any of these settings, you may access them through the RANGER II control panel. The battery must be disconnected in order to enter the parameters menu.

To access this menu, press both Arrow keys at the same time when the seconds portion of the time display indicates :01 changing to :02.

The Scroll key is used to move from selection to selection, and the Arrow keys are used to enter information. Begin by using the Arrow key to select "parameters," then press the

Scroll key to view the first parameter. To return to the idle display, press the Stop key. All parameters are automatically saved and overwrite existing parameters.

NOTE: An internal, non-rechargeable lithium battery permits the RANGER II control to retain programmed operating parameters in memory even when the charger is disconnected from an AC line. This battery has an expected service life of more than 10 years, and, when required, should be replaced by C&D. In the event of battery malfunction, contact your local C&D representative.

6.2.1. Real-time or fixed increment starting

IMPORTANT: When using real-time starting or fixed increment delay starting, be sure to allow for at least eight hours of charging before the battery is used again.

Delayed starting lets you delay the time when the charge begins in order to take advantage of lower, off-peak after the preset start time has passed, the battery will still be charged after a short delay. This allows for unusual situations, such as extended-shift where the battery would not be available until after the preset time.

NOTE: When using real-time start, if you connect a battery within four hours after the preset time has passed, the battery will still be charged after a short delay.

Real-time or fixed delay starts can be selected from the programmable parameters menu.

Use the Arrow keys to select either "Start at real time" or "Fixed delay mode." If you have selected "Start at real time" press the scroll key and use the arrow keys to enter the start time in HH:MM. If you have selected "Start after delay," press the Scroll key, and use the Arrow keys to enter the delay in HH:MM:SS. **PP: Delay mode** [$\uparrow \downarrow$]

PP: Delay $[\uparrow\downarrow]$

6.2.2. Automatic equalizing

The RANGER II control can be set to automatically equalize every 1 to 50 cycles or to equalize all batteries charged on a particular day of the week.

Automatic equalize can be set through the programmable parameters (see Section 6.2). Use the scroll key until the display reads: **PP: Equlz mode** $[\uparrow\downarrow]$

Press the Arrow keys to select either the number of cycles, the day of the week, never, or always. Depending on your selection the following displays will appear:

PP: Equiz cycl [$\uparrow \downarrow$] or **PP: Equiz mode** [$\uparrow \downarrow$]

If you have selected never or always, the next menu will be: **PP: Water Mode** $[\uparrow\downarrow]$ To return to the idle display, press the **Stop** key or the **Scroll** key to continue entering parameters. When equalization is scheduled, "**C:**(**E**)" is displayed.

If you have selected number of cycles or day of the week, press the Scroll key and use the Arrow keys to enter the appropriate information. Equalizing cycles can be programmed for two to 50 cycles

NOTE: When a RANGER II charger programmed to equalize by cycles is connected to the optional compatible battery module it will equalize by battery cycles. Otherwise, it will equalize by charger cycles.

6.2.3. Automatic watering

Provisions for automatic watering have been made within the RANGER II control.

NOTE: If a charge mode other than conventional has been selected, these do not apply and the menus will not appear. It can be set to always, never, and if a communications board has been added for a compatible battery module, every 5 cycles or every 10 cycles.

To select automatic watering, scroll through the programmable parameters until the display shows:

PP: Water mode $[\uparrow\downarrow]$

Use the Arrow keys to select watering options.

NOTE: If the automatic watering parameter is set to every 5 cycles or every 10 cycles and a battery without a compatible battery module is connected, the RANGER II will always water the battery.

Once watering has been activated, it is important that it remain activated long enough to ensure all cells have been fully watered. In order to limit possible overflow due to damage or malfunction, the RANGER II only maintains water flow for a limited duration. This time is factory set at one minute, but can be adjusted.

To adjust automatic watering time, press the Scroll key until the display reads:

PP: Set WTR tm $[\uparrow\downarrow]$

Use the Arrow keys to set the length of the watering cycle. The watering cycle can last from 15 seconds to three minutes.

6.2.4. Setting cool time

After the charge is completed, the charger will pause for a preset period of time to allow the battery to cool. Select a time from one minute to eight hours.

PP: Set cool time $[\uparrow\downarrow]$

6.2.5. Monitoring water flow

To monitor the flow of water during a watering cycle, use the Arrow keys to select "enable."

PP: Flow check $[\uparrow\downarrow]$

When the flow check is enabled, the water flow is checked soon after the watering triac is turned on. If no flow is detected, the triac is turned off and a fault appears "(- Flo)". The flow is also checked at the end of the watering cycle, and if flow is still detected, the fault will appear "(+ Flo)". All flow faults appear after the postcharge display. Disconnecting the battery clears the fault.

6.2.6. Main power override

Under certain conditions, such as troubleshooting or recovery of an overdischarged battery, it is useful to be able to override the logic of the main control board and force the charger to turn on. Press the Arrow key to activate this feature. When activated, this feature energizes the main contactor and only checks for a connected battery. The contactor will be energized for a maximum of three minutes to preclude damage to a charger or battery caused by excessive charging with defective or mismatched equipment.

PP: ctl MAIN $[\uparrow\downarrow]$

6.2.7. Water control override

The water control override feature allows the watering output to be forced on for an indefinite period for troubleshooting.

It should not be left in the ON position for an extended period of time. Use the Arrow keys to turn it on and off.

PP: CTL WATER $[\uparrow\downarrow]$

If the charge mode is set for other than conventional, the CTL water display will be replaced by the following:

P: CTL STAGE 2 $[\uparrow\downarrow]$

Use the Arrow keys to turn the second stage ON or OFF for troubleshooting purposes. Watering mode functions, including flow check, are not available in non-conventional modes.

6.2.8. Setting the number of cells

The number of cells for the charger and the RANGER II control are designed to match. After entering the programming menu, as explained above, scroll through the selections until the above display appears. Use the Arrow keys to set the number of cells to match the charger nameplate rating. You may enter from six to 36 cells in 1-cell increments.

PP: Set CELLS $[\uparrow\downarrow]$

6.2.9. Selecting the shunt size

The RANGER II control is matched to its shunt size at the factory. There should be no need to change the shunt size unless a replacement control board is installed. Should you need to change the shunt size, refer to the parts lists on pages 50 & 51 (section 9). Use the Arrow keys to set the shunt at 100 mV to 100, 200, 300, or 500 amperes. Press the Scroll key to set the shunt size.

PP: Set SHUNT $[\uparrow\downarrow]$

6.2.10. Setting the rated output current

Set the rated current of the charger as it is indicated on the charger nameplate. Use the Arrow keys to enter rated current from 0 to 500 amperes in 5-ampere increments. Press the Scroll key to set rated output current.

PP: Rated AMPS $[\uparrow\downarrow]$

6.2.11. Setting the charge mode

Use the arrow keys to select "conventional mode". The **FerroCharge** charger can only charge conventional flooded batteries. The other settings are for battery types that are not compatible with this charger.

PP: Charge Mode $[\uparrow\downarrow]$

The ready screen will indicate the mode in use. If the charger is set for conventional mode it will display: **READY** (STD): ## cells

Important: If the charger displays any mode other than (STD) the setting must be changed.

If the charger is set for low maintenance battery mode it will display: **READY (LM): ## cells**

If the charger is set for sealed battery mode it will display: READY (VR): ## cells

6.2.12. Setting the date

Set the current date by pressing the Arrow keys until the current date is displayed. The display is in MM/DD/YY format. Press the Scroll key to set the current date.

PP: Set DATE $[\uparrow\downarrow]$

6.2.13. Setting the correct time

The RANGER II charger has a 24-hour clock, which allows charger operation to begin at a preset time or at a fixed delay from time of connection. It also allows the charger to report the actual time, date and when the charge was begun and completed. The 24-hour clock is set when it leaves the factory; however it may need to be adjusted if you live in a different time zone than the factory. The correct time must be set before placing the charger in operation. Set the current time HH:MM:SS by pressing the Arrow keys until the current time is shown. Press the Scroll key to set the correct time.

PP: Set TIME $[\uparrow\downarrow]$

6.2.14. Setting the day of the week

By keeping track of weekdays, RANGER II can perform equalizing charges on the day most convenient for the user. For example, you can program the RANGER II so all Friday charges include an equalizing charge. Using the Arrow keys set the current day of the week. Press the Scroll key to set the day of the week.

PP: Set DAY $[\uparrow\downarrow]$

6.2.15. Activating daylight savings time

If the charger will be operated in an area using Daylight Savings Time, the automatic daylight savings time feature can be activated to automatically adjust the clock to daylight savings time and back to standard time on the proper days.

To activate this feature, press an Arrow key until "Auto daylight time" appears on the display. If you do not need daylight savings time, press an Arrow key until "Always STD time" appears on the display. To activate daylight savings time, press the Scroll key.

PP: Set DST $[\uparrow\downarrow]$

6.2.16. Activating and setting the address

If the Asset Management System (AMS) is in use, set the address for this charger. If the AMS is not in use set to net inactive.

PP: Set NET $[\uparrow\downarrow]$

6.2.17. Setting the baud rate

If the network is activated, set the baud rate per the instructions for the AMS.

PP: Set Baud $[\uparrow\downarrow]$

6.3. Operation

- 6.3.1. Manual starting
 - 1. CONNECT THE CHARGER TO THE AC SUPPLY LINE. The digital display will show the number of cells for which the charger has been set as well as the charge mode selected and the time of day.
 - 2. CONNECT THE BATTERY. The charge cycle will begin within five seconds, if no other delay time has been selected. The RANGER II control display will show the time remaining until the start of charge. If the battery is fully charged, the charger will move from charging to post-charge, or if manual equalize is selected, to equalize. When the charge begins, the display will show the elapsed time charging, voltage and current in amperes. When the battery is 80 percent charged, an "(80%)" will appear after the elapsed time display. If manual or automatic equalize is selected, an "(E)" will appear in the upper left hand corner. When voltage and current have stabilized "(EXT)" will appear after the elapsed time display. When equalization has begun, an "(EQU)" will appear on the display after the elapsed time. When the charge is complete, the RANGER II will show the ampere-hours and kilowatt-hours returned to the battery.

In the event of a charging problem or error, an error message will be displayed. Refer to Section 8, Troubleshooting, for more information on error messages.

NOTE: This error message will clear if the battery is disconnected. This information and other charge parameters are also available during the charge and can be accessed by pressing the Scroll key twice.

6.3.2. Manual Stopping

To interrupt the charge before it is complete, press the Stop button.

CAUTION:

Always be sure charger is turned off—either manually or automatically—before disconnecting the battery from the charger. Otherwise, hazardous arcing will occur.

6.3.3. Manual equalizing

In the course of the normal charge/discharge cycle, a motive power battery develops inequalities of voltage and specific gravity among its cells. Equalizing batteries at regular intervals will restore cell equality, assuring rated performance. Activate manual equalizing by pressing the Scroll key anytime before or during a charge. The normal equalization program is overridden, and so this feature can be used to equalize a fully charged battery. To activate manual equalize, press an Arrow key again. After 60 seconds, the display will return to the idle charger display.

MNU: Manual EQU $[\uparrow\downarrow]$

6.3.4. Operation after loss of AC power (warm start)

If the charger has been started manually, it will return to its previous operating mode as soon as power is restored and continue charging the battery until the charge cycle is completed. If the charger is set for real-time start and the power is discontinued and then restored before the selected start time, charger operation is unaffected. If the charger is set for real-time start and the power loss occurs 1) after start or 2) before start and extends into the preselected charge period, the charger will resume operation as soon as power is restored and continue the charging sequence until the charge cycle is completed. An exception to this would be if the power outage lasted into the next day (beyond 24:00, midnight), in

which case the charger would not restart until the preset hour that day. To reduce the possibility of tripping a breaker in multiple charger installations, the RANGER II control distributes charger starts randomly. The minimum delay time is 15 seconds and the maximum delay time is 3 minutes and 30 seconds.

6.3.5. Charge data retrieval

When a charge is completed, the RANGER II control can display the ampere-hours and kilowatt-hours required for the charge, followed by the word "complete." Pressing the Scroll key will enable the user to access information about starting time and date, open circuit battery voltage, starting and ending battery voltage, starting and ending battery current, ampere-hours and kilowatt-hours of charge, length of charge, ending time and date, and the number of non-equalized cycles. If the battery being charged has a compatible battery module installed and the charger is equipped for a compatible battery module communications, additional removed data will be available: ampere-hours moved on discharge and on charge temperatures. Press the Scroll key until the display reads:

MNU: Charge rpt $[\uparrow\downarrow]$

This data can be retrieved and shown on the display during or after the charge cycle. In the event of an error during the charge cycle, a "plain English" error message is displayed. Refer to Section 8, Troubleshooting.

6.4. Special features with a compatible battery module

A RANGER II charger connected with a compatible battery module will operate in the same manner as described in Sections 6.2 through 6.3, except for the enhancements noted below. While the charger is charging a battery with a compatible battery module connected, the RANGER II control checks the battery module to see that the last charge was full and the battery is discharged. It then calculates and displays the percent charged. If the battery module indicates the battery is already fully charged, the charge cycle is terminated within two minutes. The display will indicate the percent charge. The charger may enter a cooling cycle if the battery module indicates temperatures within a certain range; if it does so it is indicated on the display as **C:Cooling xx°F**, with the hours, minutes and seconds. When the battery temperature is less than 105°F, the RANGER II resumes the charge cycle and will enter the equalize mode, if necessary. After equalization or watering, the RANGER II checks the battery module again for temperature. It may enter the cooling stage again, indicating it on the display. Because the battery module keeps track of battery cycles, you can equalize and water by battery cycles, not charger cycles. If equalization is selected, the display will show "**C:E**." During equalization, the percent charge is displayed. You may specify equalizing parameters as indicated in Section 6.3. When a compatible battery module is connected to a RANGER II charger, the watering options are always, never, every five battery cycles or every 10 battery cycles.

NOTE: A battery module capable RANGER II control programmed for watering by battery cycles will always perform the watering cycle if connected to a battery without a battery module. Changing watering parameters is also described in Section 6.2.3.

6.4.1. Installing a compatible battery module communications board

The RANGER II control is designed to interface with a compatible battery module, enabling you to get data such as depth of discharge information, start and end of charge temperatures, minimum volts per cell, low volts per cell and more. In order for a RANGER II control to interface with a battery module, the charger must have a communications board installed.

The communications board is installed by inserting it into the RANGER II board at expansion slot A. Firmly seat the communications board onto the RANGER II board. (Be sure to disconnect both AC power and the battery during this procedure.)

6.4.2. Retrieving data from a compatible battery module

When entering the programmable parameters, a choice is given between the programmable parameters and the battery module menu. The battery module terminal menu is used to retrieve information from a compatible battery module

attached to a RANGER II control. If the RANGER II cannot communicate with the battery module, COMerr is displayed on the interface. If COMerr is displayed, contact your local C&D Technologies Manufacturing representative.

The following information is displayed; the Scroll key is used to move through the menu items.

Menu display	Description
BT: Present T [C] 87 °F	The current temperature of the battery.
BT: Dischrg data [C] 2.37V 329AH 14.21	Shows minimum volts per cell, ampere-hours removed and time in discharge. When this information is retrieved, the equivalent information in the charge summary report is replaced with this new data.
BT: Discharges [C] 1000 cycles	The number of discharge cycles from a compatible battery module. When this information is retrieved, the equivalent information in the charge summary report is replaced with this new data.
BT: Low VPC [C] 25 cycles 2.5%	The number of low volts per cell cycles and the percent of the total.
BT: Lo DOD cycls [C] < 250, 30-70% 700	The number of low depth of discharge cycles for 30% (indicated by "<") and 30 to 70% categories.
BT: Hi DOD cycls [C] 70-90% 45, > 5	The number of high depth of discharge cycles for 70-90% and > 90% (indicated by ">").
BT: SOC T cycls [C] < 250, 500, > 250	The number of cycles in each of three start of charge temperature categories: < 60°F (indicated by "<"), 60°F-100°F, and > 100°F (indicated by ">").
BT: EOC T cycls [C] < 250, 500, > 250	The number of cycles in each of the three end of charge temperature categories: < 60°F (indicated by "<"), 60°F-100°F, and > 100°F (indicated by ">").
BT: Power cycls [C] 2	The number of times the power to the battery module has been cycled.
BT: Status [C] SW Version 1.00	The version of the compatible battery module software.

6.5. Communications port

RANGER II controls are designed to be able to interface with a computerized asset management system (AMS). The unique fiber optic communications bus establishes a link with the AMS, enabling a user to have complete charging information on a fleet of **FerroCharge** chargers with RANGER II controls.

The network address should be set to inactive unless there is an AMS. This will hide the baud rate menu. For information on setup and using an AMS, see the AMS operating manual. For more information on the available asset management systems, ask your local C&D representative for a brochure.

7. CHARGER OPERATION

7.1. Recommended charging procedures

Chargers require little attention beyond periodic removal of dust buildup and inspection for loose connections. Refer to section 2.7, Maintenance. Proper charging procedures are important to prevent damage to chargers, batteries and operators.

Proper charging procedures require lead-acid batteries receive:

- Watering at the end of charge, as needed, to maintain proper electrolyte level and concentration;
- An equalizing charge approximately every seventh charge to correct voltage imbalances among cells;
- Periodic cleaning to remove corrosive spills;
- Freshening charges if batteries remain out of service for three or more days.

Operators should only connect batteries to chargers with matching voltage and sufficient power output. The charger must be OFF before batteries are connected or disconnected.

Motive power batteries are designed to be discharged daily but should not be discharged by more than 80 percent of their capacity during an 8-hour work shift. This allows sufficient time for them to charge and cool before they are returned to service and extends cycle life.

Charging shallow-discharged cells can also lessen battery life. Batteries discharged less than 20 percent should remain in service for another shift in light duty before being placed on the charger.

High resistance connections can reduce the charger's ability to properly charge the battery as well as reduce charging efficiency. Dirty or pitted contact surfaces on either the charger or battery connector should be cleaned and lubricated, or replaced with the identical part following the manufacturer's instructions and using the recommended tooling. Discolored contacts may also indicate loose crimps to the cable. Contacts should also be replaced if this is the case.

7.2. Operating characteristics

As a battery is placed on charge, there is an inrush of current to the battery. Charging increases battery voltage, and as the difference between the applied voltage and the battery voltage decreases, the flow of the charger current also decreases. During the final hours of the charge cycle, the charging rate is significantly reduced. Figure 7.1 shows typical ferroresonant charging characteristics.





FIGURE 7.1 TYPICAL FERRORESONANT CHARGER CURVES

As with all electrical apparatus, **FerroCharge** operating economics are influenced by electric utility rates, the user's choice of single phase or three-phase power, and the electrical efficiency and power factor of the charger.

Electric utility rates are significantly lower during off-peak periods. However, to take advantage of these rates you may need a separate electric meter for the off-peak service connection. Your local utility representative can help you determine the type of off-peak program that best fits your application.

Efficiency is the measure of the useful energy the charger makes available to the cell, as measured at the charger output. It is calculated by the equation:

Percent efficiency = Output power (kW)/ Input power (kW) x 100

The power factor is the ratio of the true power (Watts) and the apparent power (Volts x Amps) a charger actually requires to operate. The equation for determining power factor is:

Power factor (PF) = True power/Apparent power = Watts AC/(Volts AC) x (Current AC)

8. TROUBLESHOOTING

8.1. General Troubleshooting Guidelines

- 1. Safety is a prime consideration.
 - a. Think before acting; plan your actions and troubleshooting strategy
 - b. Wear safety glasses
 - c. Remove watches, rings, and jewelry before reaching into the cabinet
 - d. After recording the way you find the charger, press the Stop key, disconnect the battery and disconnect the ac supply unless a test requires otherwise.
- 2. Keep a detailed record of the initial charger condition and the control board displays in case you need to request help later. By referring to the troubleshooting chart for the control board you can probably determine the problem from the display. Record the charger and battery model numbers and serial numbers. This information will be required when requesting service or warranty support.
- 3. Visually inspect the charger displays and condition such as burn marks, smells, etc.
- 4. Determine the symptoms.
- 5. Take measurements as required.
- 6. Diagnose the problem using the troubleshooting charts as a reference.
- 7. Make the repairs.

TABLE 8.1 TEST INSTRUMENTS AND TOOLS FOR TROUBLESHOOTING

Troubleshooting Equipment
0 to 200-mV scale VOM that reads up to 600 VAC and 250 VDC with minimum accuracy of 0.5 percent
Clamp-on ammeter
SB-175 or SB-350 shorting connector
Wrench set
Screwdriver set
Jumper cables with alligator clips

Note: Diode replacement requires a supply of thermal joint compound and a torque wrench capable of achieving the values in Table 8.2.

8.2. Procedure

The following charts are designed to help a qualified technician diagnose and remedy malfunctions in the SCOUT, COMPUCHARGE, and RANGER II controls. In all cases, after recording the error message acknowledge the error message by pressing the Stop key.

The first two charts cover the control; troubleshooting instructions for the charger are presented in the third chart. Sections 8.3 through 8.4 provide information on testing and replacing components. Also refer to the wiring diagrams in Section 10.

IMPORTANT: Qualified personnel familiar with both local and national electrical codes must service this equipment.

WARNING: Line voltages are present within the battery charger cabinet. When performing the following troubleshooting procedures, be sure to observe all appropriate safety precautions. ALWAYS BE SURE THE CHARGER IS TURNED OFF BEFORE DISCONNECTING A BATTERY.

SCOUT CONTROL TROUBLESHOOTING CHART

DISPLAY STATUS	CAUSE	ACTION
Yellow LED is lit and red LED is	1. The wrong size battery has been	a. Disconnect the battery and check
flashing rapidly	connected	that the number of cells in the battery
		matches the nameplate rating of the
		charger.
		b. Disconnect the battery and check
		that the control board's jumper
		setting configuration for the number
		of cells matches the nameplate rating
		of the charger. If necessary, change
		the number of cells (see Section
		3.3.1) by moving the jumpers and
		then restoring the power to the
		charger.
	2. Battery is over-discharged	a. Press the Equal key to force the
		charger on. While the key is pressed,
		the charger will remain on. After
		battery voltage rises, release Equal
		key, disconnect and reconnect the
		automatically in the normal manner
		automatically in the normal manner.
	3. Battery has bad cells	a. Check the battery for defective
	-	cells.
Green LED is lit and red LED is	1. The maximum charging time has	a. Disconnect the battery to reset the
flashing rapidly	been exceeded	charger.
		b. Check that the charger Ampere-
		hour rating matches the battery rating.
		c. Check the charger for low dc
		output.
		d. Check the battery for defective
Doth wellow and smean LEDs are lit	1. The Step here has been proceed	cells.
and red LED is flashing repidly	1. The Stop key has been pressed	a. Disconnect the battery.
All I FDs are lit constantly	1 Watchdog timer has reset	a Disconnect AC power from the
An LLD's are in constantly	1. Wateridog tiller llas leset	charger wait 30 seconds and reapply
		If problem persists, call for service
All LEDs flashing	1. Low vpc early in the charge cycle	a. Check AC line and AC fuses to all
	due low charger output power.	phases.
		b. Check the charger for proper
		output voltage and current.

ERROR CODE	DESCRIPTION	ACTION
bU E	1. Battery voltage does not match the	a. Disconnect the battery and check
	number of cells programmed (The	that the number of cells in the battery
	wrong size battery has been	matches the nameplate rating of the
	connected.)	charger.
		b. Disconnect the battery and check
		that the control board's jumper
		setting configuration for the number
		of cells matches the nameplate rating
		of the charger. If necessary, change
		the number of cells (see Section
		4.3.3) by moving the jumpers and
		then restoring the power to the
		charger.
	2. Battery is over-discharged	a. Press the Equal key to force the
		charger on. While the key is pressed,
		the charger will remain on. After the
		battery voltage rises, release the
		Equal key, disconnect and reconnect
		the battery. The charger should start
		automatically in the normal manner.
	3. Battery has bad cells	a. Check the battery for defective
		cells.
uSE-or-uTE	1. The charger microprocessor needs	a. Charger will reset after five
	to reset itself	seconds. It will begin from the Ready
		state.
bd E	1. During charge, the battery was	a. Charger will reset itself after five
	disconnected	seconds. It will begin from the Ready
		state.
hotE	1. The battery temperature is too high	a. The charger will stop for 8 hours,
		then resume automatically. To clear
		the message, disconnect the battery.
		Let the battery cool down before
		using it.
0.00		
StPE	1. During the charge, user pressed the	a. To clear this message, disconnect
	Stop key	the battery.
12hE	1. The battery has been on charge	a To clear this message disconnect
	more than 12 hours	a. To clear uns message, disconnect
		h Check that the charger Ampere
		bour rating matches the battery rating
		c. Check the charger for low do
		output
		d Check the battery for defective
		cells
		cents.

COMPUCHARGE CONTROL TROUBLESHOOTING CHART

DISPLAY	CAUSE	ACTION		
ABORT: discnect bat	1. Battery not matched to charger (wrong number of cells)	a. Verify battery and charger match.		
Wrong battery size	2. Battery has short-circuited cells or overdischarged	a. The charger can be "forced" on from this condition by holding the "up" arrow until the voltage reads an acceptable level.		
	3. Control board not matched to charger	a. Check and reset board settings to match charger output voltage. Verify other settings.		
ABORT: discnect	1. Battery is too large for charger	a. Place battery on charger of proper size.		
bat Charge > 12 hrs	2. Control board failure	a. If problem is repeated, contact C&D		
ABORT: discnect bat Hot battery	1. Hot battery	a. Allow several hours for cool-down before flt restarting charge.		
ABORT: discnect PWR OFF, but charging	1. DC current continued to flow after contactor turned off	a. Check line contactor and replace if necessary.		
ABORT: discnect bat Operator STOP	1. Charge terminated by operator	a. Resume charge if necessary.		
ABORT: discnect bat Zero current flt	1. Operator disconnected battery	a. Reconnect battery and resume charge.		
	2. Charger problem	a. Refer to flowcharts on next page.		
ABORT: press {Stop} NVRAM is trashed	1. Charger parameters lost	a. Remove and then restore AC power; re-enter parameters. If problem recurs, call your local C&D REPRESENTATIVE.		
WDT RST: Restarting	1. Watchdog timer reset has occurred. The charger will automatically restart.	a. If problem recurs, call your local C&D REPRESENTATIVE.		
ABORT: press [Stop] Replace RTC (lobat)	1. Real-time clock must be replaced	a. Call your local C&D REPRESENTATIVE.		
ABORT: press [Stop] State machine flt	1. Control program found in an unknown state	a. Disconnect and reconnect charger. If problem persists, contact C&D.		

RANGER II CONTROL TROUBLESHOOTING CHART

POWERTRAIN AND OTHER CHARGER PROBLEM-TROUBLESHOOTING CHART

Problem	Possible Cause	Solution
Charger has no display	Loss of AC	Check AC supply fuses or breakers
		Check AC fuses in charger
		Check control fuse F3 (1-phase) or F4
		(3-phase)
		Check control transformer CXF
AC fuses or breaker blow	Charger ac input recently reconnected	Check that power transformer and
	for a different voltage	control transformer primary
		connections were both changed
		correctly. Refer to schematics.
		Check that ac fuses were changed for
		new line voltage
	Wrong fuse or breaker size	Check label in charger for internal
		fuses and recommended line fuses on
		nameplate for external fuses.
Charger will not start charging	Loss of AC	Check AC fuses or breakers
		Check charger AC fuses
	Over-discharged battery	Check for correct number of cells. On
		Scout and CompuCharge controls
		press Equal key to force on the
		charger to raise battery voltage.
	Wrong battery or board set wrong	Check that battery matches cells on
		charger nameplate
		Check that jumpers on control board
		are set to match cells on charger
		nameplate.
	Defective control transformer (CXF)	Check primary voltage and secondary
	Defective Line contactor (LC)	Check for 24 Vac on coil
	Defective control board	Check for 24 Vac on line contactor
	Defective control board	coil
Charger has no DC output	Blown output fuse (DCF)	Check for reverse polarity battery
	Diowir output fuse (Der)	Were the charger or battery
		connectors replaced recently?
		Shorted Diode
Charger does not stop	Defective control board	Press Stop. If charger keeps running,
		turn off ac. Restart ac. If charger
		starts immediately replace control
		board.
		If charger goes to delay before
		starting the control board may have
		"hung up". Resetting the ac may
		correct the problem, but if the
		problem persists it may be necessary
		to replace the board.

Low DC output, 3-phase charger	One of the power transformers is not	Check ac fuses (F1-F3)			
	working properly	Check transformer input and output			
		voltages.			
		Defective or disconnected resonant			
		capacitor			
	Diode is open in rectifier	Check diodes			
	Loose connection in output wiring	Tighten all connections			
Low DC output, 1-phase charger	Power transformer is not working properly	Defective or disconnected resonant capacitor			
		Check transformer input and output			
		voltages			
	Diode is open in rectifier	Check diodes			
	Loose connection in output wiring	Tighten all connections			
Override timer shuts down charger	Battery is over-discharged or has bad	Check battery			
	cells				
	Charger has low dc output	See chart entry for low output			
Flashing lights on Scout control	Look at section 8.2	Record display before calling for			
		service support			
Error code displayed on	Look at section 8.2	Record display before calling for			
CompuCharge control		service support			
Utility power loss and restoration	Both the Scout and CompuCharge controls will restart the charge af				
during the charge cycle	random time delay. The Scout control delay is up to 3-1/2 minutes and the				
	CompuCharge control delay is up to 2 i	minutes.			

8.3. Component testing

Many problems can often be revealed by a visual inspection. In new chargers, look for connections that may have loosened during shipment. In previously operating systems, look for the whitish powder residue created by burning varnish, or a broken, melted or discolored wire.

When troubleshooting three-phase chargers, be sure to test both sets of components.

Always read and follow all warning labels and turn off the charger before touching, removing or installing components.

C&D supports **FerroCharge** chargers with prompt field service and overnight delivery of most components. If you do not know the name of your nearest representative contact:

C&D Technologies, Inc. Integrated Power Systems, Motive Power Division 65 Industrial Park Road, Dunlap, TN 37327 Customer Service, Voice: (800) 440-3504 Customer Service, Fax: (423) 949-3647 Field Service: (800) 299-3907 Web site – <u>http://www.cdpowercom.com</u>

Device and Procedure	Device and Procedure
 CAPACITORS: Before starting, be sure the capacitor is discharged. Before testing, disconnect both leads to isolate the capacitor from the charger circuit. Test capacitors with a calibrated ohmmeter. Different sizes of capacitors require different ohmmeter range settings. Begin with the highest setting. Be sure to reverse the leads for each check. A good capacitor deflects the ohmmeter needle toward zero then steadily rises toward infinite resistance. An open capacitor immediately shows Infinite resistance. A short capacitor remains at zero resistance. 	 DIODES: Test diodes with the ohmmeter set at either the 1OX or 1OOX scale. Before testing, disconnect one lead to isolate the diode from the charger. A good diode shows low resistance when tested in one direction and high resistance when the ohmmeter probes are reversed. An open diode shows very high resistance in both directions. A shorted diode shows zero or low resistance in both directions.
CONTROL TRANSFORMER: Output should be between 22 and 26 VAC across the full secondary winding.	 FUSES: Remove the fuse from the fuse holder and test it with an ohmmeter set to any scale. A good fuse shows zero resistance. An open or "blown" fuse shows infinite resistance.

8.4. Replacing components

Ammeter shunts, capacitors, fuses, control boards, control transformers, line contactors, and power transformers can be user-replaced. Simply mate the leads of the replacement component with their appropriate connectors.

Printed circuit boards in the controls do not contain user-repairable parts. The entire printed circuit board must be replaced.

It is recommended that the entire rectifier be replaced rather than individual diodes. Users attempting diode replacement MUST observe the following procedure:

- 1) Disconnect the charger from the AC line and battery.
- 2) Remove the rectifier assembly.
- 3) Clamp the heat sink portion of the assembly in a vise.
- 4) Remove the faulty diode.
- 5) Coat the mating surfaces of the diode and the heat sink with a suitable thermal joint compound.
- 6) Place the diode on the heat sink and hand tighten the diode connection hardware.
- 7) Torque diode connections to values shown In Table 8.2.
- 8) Remove excess thermal joint compound.
- 9) Reinstall the assembly and reconnect leads.

TABLE 8.2 DIODE CONNECTION TORQUE VALUES

DIODE CONNECTION TORQUE VALUES
1/4" studs 25 +2/-2 in- lb.
3/8" studs 112 +4/-3 in- lb.
1/2" studs 137 +4/-4 in- lb.
3/4" studs 260 +5/-3 in- lb.

9. MODELS, RATINGS, AND PARTS LISTS

Model	Input Voltage	No. Of Phases	No. Of Xfmrs	Input Current	Output Current	Cells	Battery Ah Capacity for 8 h	Cabinet
	(V)			(A)	(A)		Charge, 100% DOD	
IFR6CE450	208/240/480	1	1	8.5/7.5/4	85	6	450	А
IFR6CE510	208/240/480	1	1	10.5/9/4.5	96	6	510	А
IFR6CE600	208/240/480	1	1	14/12/6	108	6	600	А
IFR6CE750	208/240/480	1	1	15/13.5/7	143	6	750	А
IFR6CE875	208/240/480	1	1	16/14/7	158	6	875	А
IFR6HK875	208/240/480	3	2	9.5/8/4	158	6	875	А
IFR6HK1000	208/240/480	3	2	11.5/10/5	190	6	1000	А
IFR6HK1200	208/240/480	3	2	16/14/7	228	6	1200	А
IFR12AC255	120/208/240	1	1	18/9/8	46	12	255	А
IFR12CE255	208/240/480	1	1	9/8/4	46	12	255	А
IFR12CE450	208/240/480	1	1	18/16/8	85	12	450	А
IFR12CE510	208/240/480	1	1	20.5/18/9	96	12	510	А
IFR12CE600	208/240/480	1	1	24/21/10.5	108	12	600	А
IFR12CE750	208/240/480	1	1	30/26/13.5	135	12	750	А
IFR12CE875	208/240/480	1	1	35/28/14	166	12	875	А
IFR12HK510	208/240/480	3	2	10/9/4.5	96	12	510	А
IFR12HK600	208/240/480	3	2	12/10.5/5.5	108	12	600	А
IFR12HK750	208/240/480	3	2	15.5/13.5/7	135	12	750	А
IFR12HK875	208/240/480	3	2	18/15.5/8	158	12	875	А
IFR12HK1000	208/240/480	3	2	20/17/8.5	190	12	1000	А
IFR12HK1200	208/240/480	3	2	23/20/10	228	12	1200	А
IFR18CE450	208/240/480	1	1	22/19/9.5	85	18	450	А
IFR18CE510	208/240/480	1	1	25/22/11	96	18	510	А
IFR18CE650	208/240/480	1	1	35.5/31.5/15.5	117	18	650	А
IFR18CE750	208/240/480	1	1	41/36/18	135	18	750	А
IFR18HK510	208/240/480	3	2	15/13.5/7	96	18	510	А
IFR18HK650	208/240/480	3	2	20/17/8.5	117	18	650	А
IFR18HK750	208/240/480	3	2	23/20/10	135	18	750	А
IFR18HK875	208/240/480	3	2	26/23/11.5	158	18	875	А
IFR18HK935	208/240/480	3	2	28.5/24.5/12	168	18	935	Α
IFR18HK1000	208/240/480	3	2	30.5/26.5/13.5	190	18	1000	А
IFR18HK1100	208/240/480	3	2	32/28/14	198	18	1100	А
IFR18HK1200	208/240/480	3	2	32/28/14	198	18	1200	А
IFR18HK1250	208/240/480	3	3	36/32/16	238	18	1250	В
IFR18HK1400	208/240/480	3	3	40/35/17.5	266	18	1400	В

Model	Input Voltage (V)	No. Of Phases	No. Of Xfmrs	Input Current (A)	Output Current (A)	Cells	Battery Ah Capacity for 8 h Charge, 100%	Cabinet
				· ·	, í		DOD	
IFR24CE450	208/240/480	1	1	31/27/13.5	85	24	450	А
IFR24CE510	208/240/480	1	1	38/33/17	96	24	510	А
IFR24CE600	208/240/480	1	1	44/38/19	114	24	600	А
IFR24CE680	240/480	1	1	46/23	129	24	680	А
IFR24HK450	208/240/480	3	2	19.5/17/8.5	85	24	450	А
IFR24HK510	208/240/480	3	2	23/20/10	96	24	510	А
IFR24HK600	208/240/480	3	2	24/21/10.5	114	24	600	А
IFR24HK680	208/240/480	3	2	27.5/24/12	129	24	680	А
IFR24HK765	208/240/480	3	2	31/27/13.5	138	24	765	А
IFR24HK850	208/240/480	3	2	35/30/15	153	24	850	А
IFR24HK900	208/240/480	3	2	36/32/16	162	24	900	А
IFR24HK1100	208/240/480	3	3	40/35/17.5	198	24	1100	В
IFR24HK1250	208/240/480	3	3	48/42/21	228	24	1200	В
IFR24K1360	480	3	3	23.5	258	24	1360	В
IFR36HK450	208/240/480	3	2	26.5/23/11.5	85	36	450	А
IFR36HK510	208/240/480	3	3	31/27/13.5	96	36	510	В
IFR36HK600	208/240/480	3	3	35/31/15.5	114	36	600	В
IFR36HK680	208/240/480	3	3	39/34/17	129	36	680	В
IFR40HK510	208/240/480	3	3	35/30/15	96	40	510	В

Model	Input Voltage	No. of Phases	No. of Xfmrs	Input Current	Output Current	Cells	Battery Ah Capacity for 8 h	Cabinet
	(V)			(A)	(A)		Charge, 100% DOD	
IFR6M450	575	1	1	4	85	6	450	А
IFR6M510	575	1	1	4.5	96	6	510	А
IFR6M600	575	1	1	6	108	6	600	А
IFR6M750	575	1	1	6.5	143	6	750	А
IFR6M875	575	1	1	7.5	166	6	875	А
IFR6L875	575	3	2	3.5	166	6	875	А
IFR6L1000	575	3	2	4	190	6	1000	А
IFR6L1200	575	3	2	5.5	228	6	1200	А
IFR12M255	575	1	1	3.5	46	12	255	А
IFR12M450	575	1	1	7	85	12	450	А
IFR12M510	575	1	1	7.5	96	12	510	А
IFR12M600	575	1	1	9	108	12	600	А
IFR12M750	575	1	1	11	135	12	750	А
IFR12M875	575	1	1	13	166	12	875	А
IFR12L510	575	3	2	4	96	12	510	А
IFR12L600	575	3	2	4.5	108	12	600	А
IFR12L750	575	3	2	6	135	12	750	А
IFR12L875	575	3	2	7	158	12	875	А
IFR12L1000	575	3	2	7	190	12	1000	А
IFR12L1200	575	3	2	8	228	12	1200	А
IFR18M450	575	1	1	8	85	18	450	А
IFR18M510	575	1	1	9	96	18	510	А
IFR18M650	575	1	1	13.5	117	18	650	А
IFR18M750	575	1	1	15	135	18	750	А
IFR18L510	575	3	2	5.5	96	18	510	А
IFR18L650	575	3	2	7.5	117	18	650	А
IFR18L750	575	3	2	8.5	135	18	750	А
IFR18L875	575	3	2	9.5	158	18	875	А
IFR18L935	575	3	2	10.5	168	18	935	А
IFR18L1000	575	3	2	11	180	18	1000	А
IFR18L1100	575	3	2	12	198	18	1100	А
IFR18L1200	575	3	2	12	198	18	1200	А
IFR18L1250	575	3	3	13	238	18	1250	В
IFR18L1400	575	3	3	14.5	266	18	1400	В

Model	Input Voltage	No. of Phases	No. of Xfmrs	Input Current	Output Current	Cells	Battery Ah Capacity for 8 h	Cabinet
	(•)			(A)	(A)		DOD	
IFR24M450	575	1	1	11.5	85	24	450	А
IFR24M510	575	1	1	14	96	24	510	А
IFR24M600	575	1	1	15.5	114	24	600	А
IFR24M680	575	1	1	19	129	24	680	А
IFR24L450	575	3	2	7	85	24	450	А
IFR24L510	575	3	2	8	96	24	510	А
IFR24L600	575	3	2	9	114	24	600	А
IFR24L680	575	3	2	10	129	24	680	А
IFR24L765	575	3	2	11.5	138	24	765	А
IFR24L850	575	3	2	12	153	24	850	А
IFR24L900	575	3	2	13.5	162	24	900	А
IFR24L1100	575	3	3	14.5	198	24	1100	В
IFR24L1250	575	3	3	17.5	228	24	1200	В
IFR24L1360	575	3	3	20	258	24	1360	В
IFR36L450	575	3	2	9.5	85	36	450	А
IFR36L510	575	3	3	11.5	96	36	510	В
IFR36L600	575	3	3	13	114	36	600	В
IFR36L680	575	3	3	14	129	36	680	В
IFR40L510	575	3	3	12	96	40	510	В

Model	Iı	nput (AC)	Output	Shunt			
	120 V	208 V	240 V	480 V	575 V *	(DC) Fuse	Amperes
						Rating	
						Amperes	
IFR6CE450	NA	12	10	6	4	200	200
IFR6CE510	NA	15	12	6	6	200	200
IFR6CE600	NA	20	15	8	7	200	200
IFR6CE750	NA	20	20	10	8	200	200
IFR6CE875	NA	20	20	10	8	200	200
IFR6HK875	NA	12	12	6	5	200	200
IFR6HK1000	NA	15	15	7	6	325	300
IFR6HK1200	NA	20	20	10	8	325	300
IFR12AC255	20	12	12	NA	NA	100	100
IFR12CE255	NA	12	10	6	5	100	100
IFR12CE450	NA	25	20	10	10	200	200
IFR12CE510	NA	30	25	12	10	200	200
IFR12CE600	NA	30	30	15	12	200	200
IFR12CE750	NA	40	35	20	15	200	200
IFR12CE875	NA	40	35	20	15	200	200
IFR12HK510	NA	15	12	6	6	200	200
IFR12HK600	NA	15	15	8	6	200	200
IFR12HK750	NA	20	10	10	8	200	200
IFR12HK875	NA	25	20	10	10	200	200
IFR12HK1000	NA	30	25	12	10	325	300
IFR12HK1200	NA	30	30	15	12	325	300
IFR18CE450	NA	30	25	12	10	200	200
IFR18CE510	NA	35	30	15	12	200	200
IFR18CE650	NA	45	40	20	20	200	200
IFR18CE750	NA	60	50	25	20	200	200
IFR18HK510	NA	20	20	10	8	200	200
IFR18HK650	NA	25	25	12	10	200	200
IFR18HK750	NA	30	25	15	12	200	200
IFR18HK875	NA	35	30	15	12	200	200
IFR18HK935	NA	40	35	15	15	325	300
IFR18HK1000	NA	40	35	20	15	325	300
IFR18HK1100	NA	45	40	20	15	325	300
IFR18HK1200	NA	45	40	20	15	325	300
IFR18HK1250	NA	50	45	20	20	325	300
IFR18HK1400	NA	50	50	25	20	500	500

* Models with M or L input voltage code only

Model	Iı	nput (AC)	Output	Shunt			
	120 V	208 V	240 V	480 V	575 V *	(DC) Fuse	Amperes
						Rating	
						Amperes	
IFR24CE450	NA	40	35	20	15	200	200
IFR24CE510	NA	50	45	20	20	200	200
IFR24CE600	NA	60	50	25	20	200	200
IFR24CE680	NA	NA	60	30	25	200	200
IFR24HK450	NA	25	25	12	10	200	200
IFR24HK510	NA	30	30	15	12	200	200
IFR24HK600	NA	30	30	15	12	200	200
IFR24HK680	NA	35	30	15	15	200	200
IFR24HK765	NA	40	35	20	15	200	200
IFR24HK850	NA	45	40	20	15	200	200
IFR24HK900	NA	50	45	20	20	325	300
IFR24HK1100	NA	50	50	25	20	325	300
IFR24HK1250	NA	60	60	30	25	325	300
IFR24K1360	NA	NA	NA	30	25	500	500
IFR36HK450	NA	35	30	15	12	200	200
IFR36HK510	NA	40	40	20	15	200	200
IFR36HK600	NA	50	40	20	20	200	200
IFR36HK680	NA	50	50	25	20	200	200
IFR40HK510	NA	50	40	20	15	200	200

* Models with M or L input voltage code only

10. SCHEMATICS AND WIRING DIAGRAMS



SCHEMATIC DIAGRAM - 208/240/480 VAC 1- PHASE



SCHEMATIC DIAGRAM - 120/208/240 VAC 1- PHASE



SCHEMATIC DIAGRAM - 208/240/480 VAC 3-PHASE



SCHEMATIC DIAGRAM - 208/240/480 VAC 3-PHASE THREE TRANSFORMERS



SCHEMATIC DIAGRAM -480 VAC 3-PHASE THREE TRANSFORMERS



SCHEMATIC DIAGRAM - 575 VAC 1- PHASE



SCHEMATIC DIAGRAM - 575 VAC 3- PHASE



SCHEMATIC DIAGRAM - 575 VAC 3- PHASE THREE TRANSFORMERS



- TERMINAL BLOCK TRANSIENT VOLTAGE SUPPRESSOR

WIRING DIAGRAM - 1 PHASE - 208/240/480 VAC



WIRING DIAGRAM - 1 PHASE - 120/208/240 VAC



WIRING DIAGRAM - 3 PHASE - 208/240/480 VAC



WIRING DIAGRAM - 3 PHASE - THREE TRANSFORMERS - 208/240/480 VAC



WIRING DIAGRAM - 3 PHASE - THREE TRANSFORMERS - 480 VAC



WIRING DIAGRAM - 1 PHASE - 575 VAC



WIRING DIAGRAM - 3 PHASE - 575 VAC



WIRING DIAGRAM - 3 PHASE - THREE TRANSFORMERS - 575 VAC